

## External connection diagram

# APR 40405 – Valve actuator 0-10V (NC)

CBFS = Fan coil control box [Step motor]

RCX = Room climate controller

LCX = Lab climate controller

BCX = Climate baffle controller

CBX = Connection box for an active supply air diffuser

