External connection diagram

RCX – Room climate controller